

Steel steering cable assembly instructions

Use an 8mm bit to drill an approx. 15-18mm deep hole from the outside into the wooden skid, into which the supplied sleeve nut should fit (position in the middle of the tip of the wooden skid). Then use a 6mm drill to drill all the way through in the middle of this hole.

The sleeve nut can now be inserted from the outside (it is advisable to apply a drop of screw locking glue to the screw-thread). Then thread the eye bolt of the steel cable and the washer onto the screw and tighten it.

